



Appendix 2: Blower Maintenance or Replacement




1. Remove the bottom louver (A).





2. With a short square head screwdriver, remove the 4 screws (C) holding in place the heat shield (B).

3. Remove and keep the heat shield (B) and the 4 screws (C).



4. Cut the Tie wrap (D).





5. Unplug the blower's electric wires (F) and (G).
6. Lift the blower (E) located under the firebox towards the back.
7. Turn 90° to pull out.

Repeat the steps in reverse order to reinstall the blower.

Blower connection

Have the wiring installed by a qualified electrician. Connect the wires from the power outlet to the terminal block, making sure that the white wire matches the white wire on the terminal. Connect the black wire with the black wire of the terminal block. The ground (green or skinned wire) must be attached to the fireplace metal frame.

