

VACUUM SWITCH CB-VACUUM-SWITCH-NS-AMP

INSTALL INSTRUCTIONS

Replaces MPNs: 720073, 28662, 28664, 720238, CB-VACUUM-SWITCH, VAC-2, 17150075, & More

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Unplug the unit.
2. Remove the side or back panel to gain access to the switch (The location of this switch will vary from model to model. Refer to the [Guide to Switches](#) for detailed information on the switch location).
3. Once you have the switch in view disconnect the two spade connectors (Pay close attention to where these connectors attach to the switch).
4. Disconnect the vacuum hose from the switch.
5. Using a small screwdriver remove the two screws holding the switch in place.
6. Install the new switch and attach it to the stove using the screws previously removed.
7. Reconnect the vacuum hose to the switch.
8. Reattach the spade connectors to the switch (The wires must attach to the same prongs, as they were installed on the previous switch.)
9. Reinstall the rear or side panel.
10. Plug in the unit.

Post-Installation Check

- Verify all connections are secure
- Ensure all wiring is not in proximity of moving parts
- Test motor operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).