

CB36 BLOWER KIT

FOR MODELS 2350, 2827, and 2941

PARTS LIST			
KEY	PART NO.	DESCRIPTION	QTY.
1	891492	ASSEMBLY, BLOWER (B36)	1
2	25598B	BOX, PAINTED BLOWER MOUNTING	1
3	83172	#10 x 1/2 TEK SCREW	8

INSTALLATION INSTRUCTIONS

- A. REMOVE PANEL BEFORE BLOWER INSTALLATION.
- B. ATTACH BLOWER MOUNTING BOX TO THE REAR OF THE UNIT USING (4) FOUR OF THE SUPPLIED #10 SCREWS.
- C. THEN MOUNT THE BLOWER ASSEMBLY TO THE MOUNTING BOX WITH THE (4) FOUR REMAINING #10 SCREWS.

