

REAR FIREBOX LINER 40258

INSTALLATION INSTRUCTIONS

Replaces MPNs: 40258

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the powersource.

2. Access the Unit

- Open the main door to the unit. The rear liner is mounted in the inside rear wall of the stove firebox.
- If the unit is a furnace with a smoke curtain, proceed to remove the smoke curtain to gain better access to the liner. This may require removal of a couple of wing screws to free the smoke curtain.

3. Remove Old Liner

- Position the 2 rear most side bricks away from the liners to free the liner.
- Lift and pull out the old rear liner from the firebox. Ensure to note which side is facing into the main area of the firebox before complete removal.

4. Install New Liner

- Insert the new liner into the mounting location in the rear of the firebox. The new liner will have a slot to slide the liner into mounting location, position the liner so it simply slides down into place along the rear wall of the unit.
- Ensure to replace the side brick that was moved in Step 3 once the liner is secure.

5. Connect Power

- Reinstall the smoke curtain removed in Step 2.
- Close the main door of the stove. Ensure the door is sealed when closed.
- Plug the stove's power cord into the power source.
- Your new shaker assembly is installed and ready to use.

Post-Installation Check

- Verify all connections are secure
- Test the seal of the door to ensure proper fitment. The door should be sealed tightly when both the handle is secured and the gasket is at proper thickness.
- Check the brick to ensure there is no sign of damage or degradation.

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.

