

HIGH TEMP THERMODISC SNAP SWITCH 80601

INSTALL INSTRUCTIONS

Replaces MPNs: 80601

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Disconnect the unit from power.
 2. Remove the rear or right side wiring access panel(s).
 3. Locate the switch on the rear wall of the stove above the convection blower.
 4. Disconnect the wires from the old switch.
 5. Unscrew the fastening screws holding the switch in place to remove the old switch from the unit.
 6. Replace the old switch with the new switch.
 7. Reconnect the wires to the new switch.
 8. Reinstall the wiring access panel(s).
 9. Reconnect power to the stove.
-

Post-Installation Check

- Verify all connections are secure
- Ensure all wiring is not in proximity of moving parts

- Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).