

VACUUM/POF SWITCH WIRE CB-SWITCHWIRE

INSTALL INSTRUCTIONS

Replaces MPNs: 11392, 11090, CB-SWITCHWIRE

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Unplug the power cord from the stove.
 2. Remove the rear or side panel needed to access the wire you're replacing.
 3. Follow the wire from the switch back to the circuit board and disconnect it. (Refer to the [Guide To Switches](#) for details).
 4. Disconnect the wire leads from the switch.
 5. Connect the new wire to the switch and plug it into the open port on the circuit board.
 6. Reinstall any panels that were removed to gain access to the wire.
 7. Plug in the unit's power cord.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).