

RHEOSTAT S.Z0136

INSTALL INSTRUCTIONS

Replaces MPNs: S.Z0136, Z0136, 136

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Unplug the unit's power cord.
 2. Locate the rheostat control. On some units, the assembly may be exposed. On others, you may need to remove a cover plate or side shield to gain access.
 3. Disconnect the spade connectors coming from the rheostat and remove it. You may need to remove the rheostat knob in order to do this.
 4. Connect to spade connectors on the new rheostat to the leads coming off the unit.
 5. Position the new rheostat in place.
 6. Reinstall the knob and any previously removed cover plates or shields.
-

Post-Installation Check

- Verify all connections are secure
- Ensure all wiring is not in proximity of moving parts
- Test motor operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).