

ANALOG CAT THERMOMETER S.Z2089

INSTALL INSTRUCTIONS

Replaces MPNs: S.Z2089

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Remove any face plate or shroud components covering the thermostat.
 2. Unscrew the fasteners holding the thermostat in place and remove. Pay special attention to the route the thermostat wires take and the position and location of the probe.
 3. Position the new thermostat in place and reinstall the previously removed fasteners. Take care to follow the same path the previous wires were running and to position the new probe in the same way.
 4. Reinstall any previously removed plates or shrouds.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).