

NON-INSULATED COPPER SPADE TERMINAL INSTALL INSTRUCTIONS

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Strip the wire sheathing on the end of the wire to expose the bare wire
 2. Twist the braided wire together.
 3. Insert the wire into the barrel end.
 4. Crimp the barrel to secure it to the wire.
 5. The wire is ready to use.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).