

Z-GRILLS CONTROLLER FOR PELLET GRILLS

Z-Grills Controller-AMP

INSTALL INSTRUCTIONS

How To Install:

1. Unplug the grill.
2. Unscrew old controller from the hopper.
3. Disconnect wires from each molex connector
4. Disconnect RTD Probe wires from green terminal block on the back of the control board.
5. Connect wire to each molex connector based on the coloring chart below.
6. Connect RTD probe to the green terminal block on the back of the control board
7. Screw the new control board back onto the hopper.
8. Plug the grill back into the wall.

Wiring Color Index:

- Yellow/White Wires: Connects to the draft inducer fan
- Green/White Wires: Connects to the auger motor
- Purple/White Wires: Connects to the igniter (hot rod)
- Black/White Wires: Connects to the power cord

Diagrams:

