

HOPPER LID LATCH ASSEMBLY 1-00-0669697

INSTALLATION INSTRUCTIONS

Replaces MPNs: 1-00-0669697

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the powersource.

2. Access the Unit

- Locate the hopper lid latch on your stove. The latch is what locks the hopper lid in place when closed and is found on the inside of the hopper.
- The latch assembly consists of the male piece on the hopper lid, and the female piece on the stove frame, the female piece will have springs and ball bearings to hold the male piece in place.

3. Remove the Lid Latch Assembly

- Remove the set screw from the male piece on the hopper lid to free and carefully remove the old male piece. Put this screw to the side for later.
- Remove the female piece from the stove frame by removing the two set screws holding it in place and set them aside. Take note of the orientation of the female piece before removal.

4. Install the Lid Latch Assembly

- Position the new female piece onto the mounting location and secure the piece with the two screws removed in Step 3. Ensure the piece is oriented in the same position like the original piece
- Position the new male piece onto the mounting location and secure the piece with the two screws removed in Step 3. Ensure the piece is oriented in the same position like the original piece with the pointed piece properly aligned with the female piece.

5. Final Assembly

- Replace the wiring access panel and secure it with the screws removed in Step 2.
- Plug the stove's power cord into the power source.
- Your new hopper lid latches are installed and ready to use.

Post-Installation Check

- Verify all mounting connections are secure.
- Inspect the hopper lid gasket and test latch operation before startup.
- Ensure the hopper lid is seated firmly against the gasket, this will indicate the latches were installed correctly and the hopper is sealed.

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.

