

104551

Convection Blower

INSTALLATION INSTRUCTIONS

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Power Disconnection

Unplug your unit from the power.

2. Access the unit

Remove the wiring access panel.

3. Disconnect Fan Wiring

Disconnect the wire to the old blower motor and capacitor from the stove. Be mindful of the location and position of each disconnected terminal

Tip: you can take a photo of the wires to note the color coding of the wires and connections before removal.

4. Remove Old Fan

- Loosen the screws holding the old blower motor in place.
- Pull out the old blower motor from the stove.

5. Install New Fan

- Install the new blower into the stove with the included mounting bracket (part 16-1045)
- Tighten the screws holding the new blower motor in place to secure the motor.

6. Connect Blower Wiring

- Connect the wiring harness to the new motor's wiring terminals.
- The ends of the wires are cut on the new and will need to be connected with wire nuts.

7. Final Assembly

Install the removed rear access panel to the stove.

8. Power Connection

Plug in the stove to test.

Post-Installation Check

- Verify all connections are secure
- Test blower operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.