

FLAME GUIDE 3-00-08534

INSTALLATION INSTRUCTIONS

Replaces MPNs: 3-00-08534, 3-00-00225

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the power source.

2. Access the Unit

Locate the burn pot on the stove. The burn pot typically sits in the front of the stove in the main burning area. The flame guide would be sitting inside the burnpot.

3. Remove Old Flame Guide

- Pull out the old flame guide out of the burn pot.
- Clean out the burn pot of any remaining ash and debris from the old flame guide.

4. Install New Flame Guide

- Insert the new flame guide into the burn pot.
- Ensure the flame guide is oriented in the same position as the original flame guide.

5. Connect Power

- Close the stove door.
 - Plug the stove's power cord into the power source.
 - Your new igniter is installed and ready to use.
-

Post-Installation Check

- Verify if the flame guide is free of cracks or damage before closing the door.
 - Ensure the pellets are burning properly and not making unusual flames.
 - Be careful not to touch the burn pot while operating the stove, allow the unit to cool completely before making any adjustments.
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.