

TEMPERATURE SENSOR 3-20-00906

INSTALL INSTRUCTIONS

Replaces MPNs: 3-20-0906

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

Unplug the stove from the power outlet.

2. Access the Unit

- Locate the temperature sensor on the stove
- Trace the temperature sensor to the jack mount connection on the back of the stove.
- For insert units, the temperature sensor will connect to the blue pigtail wires which are connected to the controller instead.

3. Disconnect Sensor

Unplug the temperature sensor wiring connector from the jack mount (or circuit board wire on inserts).

4. Connect Sensor

Connect the new sensor's wiring jack to the jack mount on the back of the stove (or circuit board wire for inserts).

5. Power Connection

Plug the stove into the power outlet to test.

Post-Installation Check

- Verify all connections are secure
 - Test sensor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.