

# AUGER FEED MOTOR 3-20-60906

## INSTALL INSTRUCTIONS

Replaces MPNs: 3-20-60906

---

### Before Installing

- **ALWAYS** unplug the unit before beginning any work
  - Allow the unit to cool completely if recently used
  - Work in a well-lit area with proper tools
  - Ensure there are no pellets in the hopper assembly
- 

### Installation Steps

1. Unplug your stove.
2. Ensure there are no pellets in the hopper.
3. Gain access to the rear of the stove.
4. Remove the rear access panel.
5. Locate the 7/16" motor set screw on the roller cam assembly and loosen it.
6. Disconnect the wires from the motor to the wiring harness
7. Pull on the auger motor to remove it. The motor will uninstall with the mounting frame attached to the motor, take a picture of the old motor with the mounting bracket attached for reference.
8. Transfer the mounting frame to the new motor in the same orientation as the old motor.
9. Install the new auger motor with the mounting frame
10. Connect the wires from the new motor to the wiring harness.
11. Connect the motor to the auger shaft with the 7/16" set screw on the roller cam assembly.
12. Reinstall the rear access panel.

13. Plug in the stove.

---

## Post-Installation Check

- Verify all connections are secure
  - Ensure all wiring is not in proximity of moving parts
  - Test motor operation before closing panels
  - Check for any unusual noises or vibrations
- 

## Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).