

BRICK RETAINER 40132

INSTALLATION INSTRUCTIONS

Replaces MPNs: 40132

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the powersource.

2. Access the Unit

- Open the cabinet door
- Locate the thermostat assembly. The thermostat is located on the backside of the front cabinet panel.
- Remove the "S" shaped hook and chain from the thermostat. The hook may need to be carefully bent slightly to remove it.
- Open the lid on the top of the stove.
- From the lid opening, remove the nut and bolt from the bracket coming from the back of the stove to the cabinet.
 - Use a wrench to secure the nut and a phillips screwdriver to loosen the bolt and remove it. Repeat this step for the opposite side and set all these removed nuts and bolts safely to the side for later.
- Close the lid on the stove.

- Go to the bottom ledge on the front of the stove and remove the four nuts from the weld studs that are on the bottom of the cabinet and set these aside.
- Remove the four nuts from the weld studs that are on the back of the cabinet on the bottom and set these aside. The cabinet is now free from the stove.
- The cabinet will need to be removed in order to access the bolts attaching the brick retainer to the stove. Lift the cabinet up and off of the stove. Two people may be needed to lift the cabinet off the unit.
- Open the feed door.

3. Remove Old Retainer

- With a wrench, hold the nut still on the outside of the stove while you loosen the bolt and remove it from the inside of the firebox with a flathead screwdriver. Continue to repeat this step for the remaining two nuts and bolts until the brick retainer is free from the unit.
 - Make sure to safely set aside the removed nuts and bolts for use later on.
- Lift and pull the old brick retainer forward to remove the brick retainer from the stove.
- Repeat removal measures for the other brick retainer if replacing both retainers.

4. Install New Retainer

- Insert the new retainer(s) into the unit with the single-hole ledge facing down and the ledge with six holes facing upward to the side of the firebox. Ensure to also line up the retainer mounting holes with the holes in the firebox
- Insert and tighten the three nuts and bolts removed in Step 3. Tighten the nuts and completely use the wrench and screwdriver, but make sure not to overtighten them and risk damaging the nuts and bolts.

5. Connect Power

- Close the feed door.

- Reinstall the cabinet to the stove. Secure the cabinet to the bottom of the stove with the nuts removed in step 2
 - Open the top lid on the stove and secure the brackets coming from the back of the stove to the cabinet with the nuts and bolts removed in Step 2.
 - Open the front cabinet panel and attach the "S" hook and chain to the thermostat.
 - Carefully bend the hook back in place to secure it to the thermostat if necessary.
 - Close the cabinet door of the stove. Ensure the door is sealed when closed.
 - Plug the stove's power cord into the power source.
 - Your new brick retainer(s) are installed and ready to use.
-

Post-Installation Check

- Verify all connections are secure
 - Test the seal of the door to ensure proper fitment. The door should be sealed tightly when both the handle is secured and the gasket is at proper thickness.
 - Ensure the hardware for both the retainers and the cabinet are secured to the stove before final assembly.
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.