

FURNACE GRATE 40263

INSTALLATION INSTRUCTIONS

Replaces MPNs: 40263

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the powersource.

2. Access the Unit

- Open the main door to the unit. The grate will be sitting on the inside of the stove firebox.
- The unit will require the removal of the front or rear liners to access the ends of the grate(s). Proceed to position the obstructing bricks away from the liner closest to the grate you are replacing and pull out the liner to access the grate. Ensure to note the position of each firebrick prior to removal.
 - If replacing both grates in your unit, proceed to remove both front and rear liners.

3. Remove Old Grate

Lift the old grate up from the grate supports and out of the unit.

4. Install New Grate

Insert the new grate into the firebox, ensuring it sits in the bottom on the grate supports.

5. Connect Power

- Reinstall the firebox liners removed in Step 2.
 - Replace the side brick removed in Step 2. Ensure the bricks are in the same positions as before.
 - Close the main door of the stove. Ensure the door is sealed when closed.
 - Plug the stove's power cord into the power source.
 - Your new grate is installed and ready to use.
-

Post-Installation Check

- Verify all connections are secure
 - Test the seal of the door to ensure proper fitment. The door should be sealed tightly when both the handle is secured and the gasket is at proper thickness.
 - Check the grates to ensure they interlock properly and turn smoothly when operated.
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.

