

GRILL COVER 73701

INSTALLATION INSTRUCTIONS

Replaces MPNs: CGC-4465, 73701

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Disconnect Power

- Ensure the grill is completely cooled down and drained of power.
- Unplug the stove from the powersource.

2. Prepare the Unit

- Ensure the grill has been thoroughly cleaned after use.
- If storing the unit for a long period of time, proceed to clean and condition the grill's cooking area, including the bottom of the barrel.
 - If the unit is a pellet grill, make sure the hopper and feed system has been cleared of any and all pellets. Depending on the environment, the pellets can clump and cause issues for the system if left exposed to moisture.

3. Install the Cover

- Unfold the cover, verify the shape before proceeding and inspect for any small tears.
- Position the bottom opening of the cover over the unit.

- Carefully slide the cover down toward the bottom of the unit. Make sure to guide the cover so it mostly conforms to the shape of the grill.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).