

EXHAUST BLOWER 80495

INSTALL INSTRUCTIONS

Replaces MPNs: 80495

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Unplug the unit and make sure it is cool to the touch.
 2. Remove the necessary panels from the furnace (You may need to remove the rear and side panels).
 3. Remove or unplug your RDT temp sensor and disconnect the power wires leading to the draft blower.
 4. Remove the screws attaching the blower housing to the unit. You may need to disconnect the exhaust pipe from the unit.
 5. Remove the old gasket. Using a flathead screwdriver scrape and remove any pieces of old gasket stuck to the housing or body of the unit.
 6. Position the new gasket in place and install the new blower with the previously removed screws.
 7. Reconnect the RDT temp sensor and power wires.
 8. Reconnect and seal the exhaust (If it was removed)
 9. Reinstall any previously removed panels.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).