

80P20001-R

Exhaust Blower

INSTALLATION INSTRUCTIONS

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Power Disconnection

Unplug the unit from the power source.

2. Access the Unit

Open the wiring access panel toward the rear of the unit.

3. Disconnect Wiring

- Disconnect all wiring from the blower
- **Tip:** Take a photo of wire connections before disconnecting

4. Remove Old Blower

- Unscrew the bolts holding the exhaust blower mount to the housing.
- Remove the old exhaust blower and gasket.

5. Install New Blower

Install the new exhaust blower motor and gasket to the stove.

6. Connect Wiring

- Connect the new control board wires to the stove wiring harness.

- This new motor will fit older 3 wire stove models with black/white/brown wire leads as well as newer 2 black/white wire models with digital controls.
- The exhaust blower can connect to newer 2 wire models by not utilizing the 3rd wire (brown) and leaving it unconnected.

7. Final Assembly

Close the wiring access panel.

8. Power Connection

Plug the stove back into the power source.

Post-Installation Check

- Verify all connections are secure
- Test blower operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.