

CONVECTION BLOWER GASKET 89319

INSTALLATION INSTRUCTIONS

Replaces MPNs: 89319

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the powersource.

2. Access the Unit

Locate the convection blower on the stove. The blower is typically mounted to the back of the stove. Depending on your unit, there may be two of these blowers installed. The gasket will be located under the flange where the blower is mounted.

3. Remove Old Blower Gasket

Remove the 4 bolts from each blower mount and gently pull the old blower and mounting gasket from the stove.

4. Install New Blower Gasket

- Position the blower motor(s) and new mounting gasket(s) onto the mounting location and ensure the new blower is oriented in the same position as the old blower.

- Secure the blower and gasket using the 4 bolts removed in Step 4. Tighten until snug, do not overtighten, as excessive force can damage the bolt or strip the bolt holes.

5. Connect Power

- Replace the wiring access cover and secure it with the screws removed in Step 3.
 - Plug the stove's power cord into the power source.
 - Your new blower is installed and ready to use.
-



Post-Installation Check

- Verify all connections are secure
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-



Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.