

BLOWER-HP22

Convection Blower

INSTALLATION INSTRUCTIONS

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Power Disconnection

Unplug the unit from the power source and ensure it has cooled completely.

2. Access the Unit

Remove the rear and side access panels from the stove to access the blower (You may not need to remove all three panels).

3. Disconnect Blower Wiring

Disconnect both power wires running to the fan motor.

4. Remove Old Blower

- Loosen the 4 Allen bolts attaching the mounting bracket to the stove
- Remove the fan assembly.

5. Install New Blower

- Position the new fan assembly in place
- Reinstall the 4 previously removed Allen bolts.
- If your HP22 (Pre 2016) have blowers with upper mounts, part # Blower1-HP22-Upper will be needed on these units instead.

6. Connect Blower Wiring

Connect the previously removed power wires to the tabs on the new motor.

Tip: The wiring terminals on the blower are non-polarized, so the wires from the wiring harness can connect to either of the terminals.

7. Final Assembly

Securely install any stove panels that were previously removed.

8. Power Connection

Plug the stove back into the power source.

Post-Installation Check

- Verify all connections are secure
- Test blower operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.