

CAPACITOR CB-CAPACITOR

INSTALL INSTRUCTIONS

Replaces MPNs: 720288, AMC

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

1. Unplug the power cord from the wall outlet.
 2. Remove the rear and side panels of the unit (You may only need to remove one panel).
 3. Locate the capacitor (It can be found on or near the wiring harness for the auger/ feed motor).
 4. Unplug and remove the old capacitor.
 5. Plug in the new capacitor connector.
 6. Reinstall the side and rear panels.
 7. Plug the unit's power cord back into the wall outlet.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).