

CONVECTION BLOWER F500308

INSTALL INSTRUCTIONS

Replaces MPNs: CB36, HB50, 80442, 69354, 891492

How to install

Installation will vary depending on the unit you have. On some models, the blower can be accessed by removing panels from the unit. On others, the blower motor will be housed in a removable cage mounted on the rear of the stove.

1. Unplug the unit and make sure it is cool to the touch.
2. Remove the necessary panels from the unit to allow access to the convection blower (You may need to remove the side panel in addition to the rear panel).
3. Disconnect the power wires leading to the blower.
4. Remove the screws attaching the blower housing to the unit. **Pay special attention to the orientation of the blower and any grommets/spacers. The replacement blower needs to be positioned in the same way.**
5. Position the new blower assembly in place and reinstall the previously removed screws.
6. Reconnect any previously removed power wires.
7. Reinstall any previously removed panels.
8. Plug in the unit.