

POWER SUPPLY CORD 80461

INSTALL INSTRUCTIONS

Replaces MPNs: 80461, Powercord1, C-E-060, 720045, PowerCord1, 3-20-51578, 812-1180, & More

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

This cord is the main connection responsible for bringing power to the stove. This cord plugs into the stove's power supply and wall outlet. If your stove will not power on, verify that the end of the cord is seated into the power supply and that no fuses on the main control board are blown. If you verify that the previously mentioned items are not causing the power issue and you have confirmed that you have power at the wall outlet this cord may need to be replaced.

1. Ensure that the unit has been fully turned off.
 2. Disconnect the old power cord from the wall outlet.
 3. Disconnect the old power cord from the unit's power supply.
 4. Connect the new power cord to the unit's power supply.
 5. Connect the new power cord to the wall outlet.
 6. Turn on the unit to verify proper operation.
-

Post-Installation Check

- Verify all connections are secure
 - Ensure all wiring is not in proximity of moving parts
 - Test motor operation before closing panels
 - Check for any unusual noises or vibrations
-

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).