

HOPPER SWITCH SWITCH HOPSWITCH2-AMP

INSTALL INSTRUCTIONS

Replaces MPNs: 720055, 23074, HopSwitch2

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

Unplug the stove from the power outlet.

2. Access the Unit

- Remove the screws securing the wiring access panel to the stove.
- Carefully remove the wiring access panel and set it aside.
- Open the hopper lid.

3. Disconnect Wiring

Unplug the hopper switch wiring connector from the circuit board.

4. Remove Old Hopper Switch

Gently pull the old switch out from the stove.

5. Install New Hopper Switch

- Insert the new switch into the same location of the old switch in the same orientation.
- Ensure the switch is inserted wire first and seated firmly to the stove.

6. Connect Wiring

- Connect the new hopper switch wiring connector to the circuit board.
- Ensure the wires are connected to the same terminal as on the old switch.

7. Final assembly

Install the wiring access panel onto the stove with the mounting hardware removed prior.

8. Power Connection

Plug the stove into the power outlet to test.



Post-Installation Check

- Verify all connections are secure
- Test sensor operation before closing panels
- Check for any unusual noises or vibrations



Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.