

COOKING GRATES KIT0446

INSTALLATION INSTRUCTIONS

Replaces MPNs: KIT0446, HDW397, HDW444

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the grill from the power source.

2. Access the Unit

- Open the main grill lid.
- Locate the upper cooking grate in the grill. The upper grate is mounted in the middle of the grill's cooking space, sitting right above the main cooking grates on the bottom.

3. Remove Old Grate

- Lift the grate out from the mounting holes in the grate side supports and disengage it from the grate grill.
- Pull the old grate out from the grill to remove it.

5. Install New Grate

- Insert the new upper grate into the grill centered side to side with the rear bent edge inserted first. Ensure the 4 mounting "legs" are pointed downward.

- Align the legs with the holes in the grate side supports. Proceed then to insert the legs into the holes until the sides of the grate sits flush to the side supports.

6. Connect Power

- Close the main grill lid.
- Plug the grill's power cord into the power source.
- Your new cooking grates are installed and ready to use.

Post-Installation Check

- Verify if the grates sits flush inside the grill before final assembly
- Be careful not to touch the grill while testing or operating, allow the unit to cool completely before making any adjustments.

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.