

# N111570

## Convection Blower

### INSTALLATION INSTRUCTIONS

---

#### Before Installing

- **ALWAYS** unplug the unit before beginning any work
  - Allow the unit to cool completely if recently used
  - Work in a well-lit area with proper tools
- 

#### Installation Steps

##### 1. Power Disconnection

Unplug your stove from the power.

##### 2. Access the unit

- Remove the stove wiring access panels from the side of the stove.
- If your model is a fireplace insert, remove the shroud and pull the stove out to access these panels.

##### 3. Disconnect Blower Wiring

Unplug the convection blower wiring connectors from the wiring harness.

**Tip:** you can take a photo of the wires to note the color coding of the wires and connections before removal.

##### 4. Remove Old Blower

- Remove the bolts that fastens the blower assembly to the stove.
- Remove the old blower assembly from the stove.
- Remove the blower from the blower mounting bracket

##### 5. Install New Fan



- Install the new blower to the existing blower mounting bracket.
- Install the old blower assembly from the stove using the fastening bolts removed prior.

**Note:** If you have a pre-2006 unit, blower 104551 should be installed to your unit instead. Said blower includes the mounting bracket necessary to install the blower in older units.

## 6. Connect Blower Wiring

Plug the blower wiring connectors back into the wiring harness in the same connections as the original blower.

## 7. Final Assembly

- Install the removed wiring access panels.
- For fireplace inserts, push the stove back into the fireplace and install the shroud.

## 8. Power Connection

Plug in the grill to test.

---

## Post-Installation Check

- Verify all connections are secure
- Test blower operation before closing panels
- Check for any unusual noises or vibrations

---

## Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.