

# PESBR084

## Convection Blower

### INSTALLATION INSTRUCTIONS

---

#### Before Installing

- **ALWAYS** unplug the unit before beginning any work
  - Allow the unit to cool completely if recently used
  - Work in a well-lit area with proper tools
- 

#### Installation Steps

##### 1. Power Disconnection

Unplug your stove from the power.

##### 2. Access the unit

- Remove the wiring access panel on the hopper assembly to access the fan.
- The blower access panels are typically located toward the front of the unit in most models.

##### 3. Disconnect Blower Wiring

Unplug the fan wiring connectors from the blower control assembly.

**Tip:** you can take a photo of the wires to note the color coding of the wires and connections before removal.

##### 4. Remove Old Blower

- Unfasten the mounting plate that holds the convection blower.
- Pull the blower and mounting plate from the convection area.
- Remove the old convection blower from the mounting plate

## 5. Install New Blower

- Install the new convection blower from the mounting plate.
- Install blower and mounting plate from the convection area.
- Fasten the mounting plate that holds the convection blower.

## 6. Connect Blower Wiring

Plug the blowers wiring connectors into the blower control assembly wires in the same connections as the original blower.

## 7. Final Assembly

Install the removed blower access panels.

## 8. Power Connection

Plug in the stove to test.

---

## Post-Installation Check

- Verify all connections are secure
- Test blower operation before closing panels
- Check for any unusual noises or vibrations

---

## Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.