

DIGITAL CONTROL BOARD PU-CB14

INSTALL INSTRUCTIONS

Replaces MPNs: PU-CB14

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
 - Ensure there are no pellets in the hopper assembly
-

Installation Steps

BEFORE REPLACING THE CONTROL BOARD, Make sure the unit has completely cooled down and that the stove has been unplugged.

1. Unplug the power cord from the wall outlet.
 2. Remove the front face of the control board by pulling it forward.
 3. Once the board is apart, use a pair of needle nose pliers to disconnect the wiring harness, room sensor, heat sensor, hopper lid, and vacuum switch connectors.
 4. Reconnect the components previously removed to the new board.
 5. Snap the front face of the control panel back into place.
 6. Plug the unit into the wall outlet.
-

Post-Installation Check

- Verify all connections are secure
- Ensure all wiring is not in proximity of moving parts
- Test motor operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our [contact form](#).