

BYPASS HANDLE S.Z2052

OPERATION INSTRUCTIONS

Replaces MPNs: S.Z2052, Z2052

Operation Warning

- **ALWAYS** use the bypass handle when operating the bypass damper.
 - **DO NOT** attempt to operate the bypass directly with your hands, you could risk burn injuries since the bypass rod can get very hot
-

Installation Steps

1. Access the Unit

Locate the bypass damper control on the assembly, this would be the rod inserted above the main door of the unit door.

3. Acquire the Handle

This handle **does not** permanently install on the unit. It is used to grab or push the bypass latch. When not in use, the handle is hung as a separate part on the left or right notch below the ash lip of the appliance. Remove the handle from the mounting on the stove when you need to open or close the damper.

4. Operate the Bypass

- Use the end of the bypass handle to operate the bypass rod. See diagrams on page 3 for further reference.
- To open the bypass damper, hook the handle onto the side of the bypass latch on the end of the bypass rod and pull the rod out toward you (Fig. A).

- To close the bypass damper position the tip of the bypass handle onto the center of the bypass latches and push the bypass rod into the unit (Fig. B).

5. Return the Handle

Hang the handle back onto the left or right notch below the ash lip of the appliance.

Post-Operation Check

When the stove is not in use, ensure that the damper is set to the closed position.

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.

Diagram

