

HIGH LIMIT SNAP SWITCH SNAP-34

INSTALL INSTRUCTIONS

Replaces MPNs: RWZ102659, 18253, 12147705, 12127705,
KS-5100-1330

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

Unplug the stove from the power outlet.

2. Access the Unit

- Remove the screws securing the wiring access panel to the stove.
- Carefully remove the access panel and set it aside.

3. Disconnect Wiring

Unplug the wiring leads of the wiring harness from the high limit switch.

4. Remove Old High Limit Switch

- Remove the screws from the high limit switch mount to free the switch.
- Pull the old switch out from the stove.

5. Install New High Limit Switch

- Insert the new switch into the same location of the old switch in the same orientation.
- Secure the snap disc in place with screws.

6. Connect Wiring

- Connect the wiring leads from the wiring harness to the new switch's wiring terminals.
- The switch's wiring terminals are non-polarized, so either wire can connect to either terminal.

7. Final assembly

Install the rear access panel onto the stove with the mounting hardware removed prior.

8. Power Connection

Plug the stove into the power outlet to test.

Post-Installation Check

- Verify all connections are secure
- Test sensor operation before closing panels
- Check for any unusual noises or vibrations

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.