

# TEMPERATURE SNAP DISC SNAP-43

## INSTALL INSTRUCTIONS

Replaces MPNs: 145-1142-A

---

### Before Installing

- **ALWAYS** unplug the unit before beginning any work
  - Allow the unit to cool completely if recently used
  - Work in a well-lit area with proper tools
- 

### Installation Steps

#### 1. Disconnect Power

Unplug the stove from the power outlet.

#### 2. Access the Unit

- Remove the screws securing the wiring access panel to the stove.
- Carefully remove the access panel and set it aside.

#### 3. Disconnect Wiring

Unplug the wiring leads of the wiring harness from the Snap Disk.

#### 4. Remove Old Snap Disc

- Remove the screws from the snap disc mount to free the snap disc.
- Pull the old snap disc out from the stove.
- If a mounting gasket is present, remove the gasket when removing the snap disc.

#### 5. Install New Snap Disc

- Insert the new snap disc (and gasket if present) into the same location of the old snap disc in the same orientation.

- Secure the snap disc in place with screws.

## 6. Connect Wiring

- Connect the wiring leads from the wiring harness to the new snap disc's wiring terminals.
- The snap discs wiring terminals are non-polarized, so either wire can connect to either terminal.

## 7. Final assembly

Install the rear access panel onto the stove with the mounting hardware removed prior.

## 8. Power Connection

Plug the stove into the power outlet to test.



## Post-Installation Check

- Verify all connections are secure
- Test sensor operation before closing panels
- Check for any unusual noises or vibrations



## Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.