

HIGH LIMIT SNAP DISC SNAP-6

INSTALL INSTRUCTIONS

Replaces MPNs: 80601, 15011, 330784L, H5891, 32103, TDK0MR01

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

Unplug the stove from the power outlet.

2. Access the Unit

- Remove the screws securing the wiring access panel to the stove.
- Carefully remove the access panel and set it aside.

3. Disconnect Wiring

Unplug the wiring leads of the wiring harness from the High Limits Snap Disk.

4. Remove Old Snap Disc

- Remove the screws from the snap disc mount to free the snap disc.
- Pull the old snap disc out from the stove.
- If a mounting gasket is present, remove the gasket when removing the snap disc.

5. Install New Snap Disc

- Insert the new snap disc (and gasket if present) into the same location of the old snap disc in the same orientation.

- Secure the snap disc in place with screws.

6. Connect Wiring

- Connect the wiring leads from the wiring harness to the new snap disc's wiring terminals.
- The snap discs wiring terminals are non-polarized, so either wire can connect to either terminal.

7. Final assembly

Install the rear access panel onto the stove with the mounting hardware removed prior.

8. Power Connection

Plug the stove into the power outlet to test.



Post-Installation Check

- Verify all connections are secure
- Test sensor operation before closing panels
- Check for any unusual noises or vibrations



Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.