

FIREPOT BOTTOM SRV7034-153

INSTALL INSTRUCTIONS

Replaces MPNs: SRV7034-153

Before Installing

- **ALWAYS** unplug the unit before beginning any work
 - Allow the unit to cool completely if recently used
 - Work in a well-lit area with proper tools
-

Installation Steps

1. Disconnect Power

- Ensure the unit is completely cooled down and drained of power.
- Unplug the stove from the power source.

2. Access the Unit

- Locate the burn pot on the stove. The firepot typically sits in the main burning area of the stove.
- Remove the ash pan from the stove to access the bottom of the burn pot.

3. Remove Old Firepot

- From under the firepot, remove the 4 hitch pins from the four spring hangers to lower the auto-clean assembly.
- Disconnect the firepot bottom from the autoclean arm and linkage.
- Pull the old firepot bottom out of the stove.

4. Install New Burn Pot

- Insert the new firepot bottom and secure it to the arm and linkage.

- Raise the assembly from under the spring hangers and lock each hanger with the 4 hitch pins removed in step 3.

5. Connect Power

- Install the ash pan to the stove.
- Close the stove's front door.
- Your new igniter is installed and ready to use.

Post-Installation Check

- Verify all connections are secure
- Test igniter operation before closing panels. The igniter should visually glow red hot and emit heat.
- Be careful not to touch the igniter rod while testing or operating, allow the unit to cool completely before making any adjustments.

Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.