

# PELPRO CONTROL BOARD SRV7077-050

## INSTALLATION INSTRUCTIONS

---

### Before Installing

- **ALWAYS** unplug the unit before beginning any work and wait at least 5 minutes for internal components to discharge.
  - Allow the unit to cool completely if recently used, interior surfaces can retain heat for over an hour.
  - Work in a well-lit area on a clean, flat surface.
- 

### Installation Steps

#### 1. Disconnect Power

- Turn the dial control to the off position and ensure the unit is completely powered down.
- Unplug the stove's power cord from the power source.

#### 2. Access the Unit

- Locate the control panel in the unit's wiring compartment. Location varies by model, it is most commonly on the side of the stove. Refer to your stove's owner's manual for the exact panel location on your model.
- Remove the screws securing the rear wiring access panel and set them aside in a small container so they don't get lost.
- Carefully lift the panel away. Some models have wiring tethered to the panel itself, pull slowly and check before fully removing.

#### 3. Disconnect Wiring

- Before disconnecting anything, take clear photos of all wiring connections from multiple angles. This is the single best way to avoid mistakes during reassembly.

- Label each connector with masking tape and a marker as you remove it.
- Unplug all stove wiring from the control board, including the main connector for the wiring harness.
  - **Note:** Always pull on the connector body, never on the wires themselves, pulling on wires can damage the connector or break the crimp.

#### 4. Remove Old Control Board

- With needle nose pliers, pinch the 4 plastic pins that secure the circuit board to the mount.
- Push in the pins through the corner holes of the control board to disengage and carefully remove the old control board.

#### 5. Install New Control Board

- Carefully slot the new control board's corner holes onto the control panel mounting pins. Ensure the board is oriented so the USB port is positioned at the top of the board.
  - **NOTE:** Hold the board by the edges, touching the metal on the bare silicone board could damage the component. If your new control board does not include 4 control board connector pins, you can reuse the connector pins from your old board.
- Secure the control board to the mount by carefully pushing the board onto the pins until the pins are snapped in place through the board.

#### 6. Connect Wiring

- Using the reference photos and labels from Step 3, plug all stove wiring into the new control board.
- Reconnect the main wiring harness connector, dial control connector, and any remaining connectors.
- Ensure each connector is fully seated, you should feel or hear it click into place. A loose connection is the most common cause of post-installation issues.

*Please refer to page 4 for the wiring diagram.*

## 7. Connect Power

- Replace the wiring access panel and secure it with the screws removed in Step 2.
  - Plug the stove's power cord into the power source.
  - Your new control board is installed and ready to use.
- 

## Post-Installation Check

- Verify all connections are secure and the access panel is fully reinstalled
  - Power on the unit. The control board display should illuminate within a few seconds.
  - Confirm the display reads correctly and responds to button inputs
  - Run the unit through a normal startup cycle and listen for proper fan and auger operation.
  - Check for any unusual noises, vibrations, or smells, if any are present, immediately unplug the unit and review your wiring connections
  - If the display shows an error code, refer to your manual's troubleshooting section.
- 

## Support

If you encounter any issues during installation, consult your owner's manual or contact technical support via our contact form.

## Wiring Diagram

